

**CEMENT, ASBESTOS SHINGLES****REPRESENTATIVE SURFACES**

Homes
Buildings

GENERAL**Glazed Shingles**

Should not be finished until glaze has weathered from the surface, usually in about two years.

Weathered & Unglazed

If material has started to erode or "sand", a coat of Stonite® Waterborne Acrylic Masonry Primer 7007 must be applied before finishing to insure adhesion of the top coats.

SURFACE PREPARATION

WARNING! If you scrape, sand or remove old paint from any surface, you may release lead dust. LEAD IS TOXIC. EXPOSURE TO LEAD DUST CAN CAUSE SERIOUS ILLNESS, SUCH AS BRAIN DAMAGE, ESPECIALLY IN CHILDREN. PREGNANT WOMEN SHOULD ALSO AVOID EXPOSURE. Wear a NIOSH-approved respirator to control lead exposure. Carefully clean up with a wet mop or HEPA vacuum. Before you start, find out how to protect yourself and your family by contacting the U.S. EPA/Lead Information Hotline at 1-800-424-LEAD (5323) or log on to www.epa.gov/lead.

- Wash with a garden hose to remove surface contamination. (Power washing or scrubbing are not recommended as they disturb asbestos fibers.)

PRIMERS

- Stonite® Waterborne Acrylic Masonry Primer #7007



PRODUCT RECOMMENDATIONS - CEMENT, ASBESTOS SHINGLES

PRIMERS	FINISH COATS
<ul style="list-style-type: none">• Stonite® Waterborne Acrylic Masonry Primer 7007	<ol style="list-style-type: none">1. 2010® Interior 100% Acrylic Flat, Eggshell or Satin Gloss2. Fres~Coat 100% Acrylic Latex House Paint Velvet Flat3. Fres~Coat 100% Acrylic Latex Satin Gloss House & Trim4. Pacific® Latex Flat5. Pacific Latex Satin Gloss