



PVC TRIMBOARDS (AZEK, KLEER)

REPRESENTATIVE SURFACES

Standing Exterior Trim

SURFACE PREPARATION

Clean trimboards of any surface contaminants using detergents such as liquid Spic & Span® and warm water. Rinse with clean water.

Scuf-sand trimboards using a fine to medium grit sandpaper.

Remove sanding residue using a vacuum brush followed by a detergent and warm water washing and clean water rinse.

* Only for use with paint LRVs above 55.



PVC TRIMBOARDS (AZEK, KLEER)

EXPOSURE CONDITIONS	PRIMER	TOPCOAT
Average exterior exposure.	No primer required.	2 coats of : Fres~coat TM Exterior 100% Acrylic Latex Low Lustre or Satin Gloss House & Trim Paint OR 2010 Exterior 100% Acrylic Latex Eggshell or Satin Gloss House & Trim Paint