

**WOOD, PLYWOOD****REPRESENTATIVE SURFACES**

Trim	Cabinets
Woodwork	Furniture
Doors	Paneling

**GENERAL**

Interior finish wood products should be properly kiln dried with a moisture content of less than 10% when installed.

**SURFACE PREPARATION**

**WARNING!** If you scrape, sand or remove old paint from any surface, you may release lead dust. LEAD IS TOXIC. EXPOSURE TO LEAD DUST CAN CAUSE SERIOUS ILLNESS, SUCH AS BRAIN DAMAGE, ESPECIALLY IN CHILDREN. PREGNANT WOMEN SHOULD ALSO AVOID EXPOSURE. Wear a NIOSH-approved respirator to control lead exposure. Carefully clean up with a wet mop or HEPA vacuum. Before you start, find out how to protect yourself and your family by contacting the U.S. EPA/Lead Information Hotline at 1-800-424-LEAD (5323) or log on to [www.epa.gov/lead](http://www.epa.gov/lead).

- Fill all holes and voids with prepared patching compound or joint compound
- Sand to obtain smooth surface.
- Brush to remove dirt and sanding residue.

**PRIMERS**

Spot prime any knots or resin areas with Wipe-Out® Alkyd or Wipe-Out® 100% Acrylic Latex Stain Block

Best—	Fully prime with... 100% Acrylic Latex Enamel Undercoat 54600 ASAP® 50300
Good—	Fully prime with... AllWall® Primer 56600 Pro2000® Primer Sealer 55400 ProPrime® 54500

For fine finish work where a smooth sanding primer is required, fully prime with Fres~Coat® Alkyd Enamel Undercoat 20200.



**PRODUCT RECOMMENDATIONS - WOOD, PLYWOOD**

LATEX PRIMERS	FINISH COAT
<ul style="list-style-type: none"> <li>• ASAP® 50300</li> <li>• 100% Acrylic Latex Enamel Undercoat 54600</li> <li>• AllWall® Primer 56000</li> <li>• Pro 2000® Primer-Sealer 55400</li> <li>• ProPrime® 54500</li> </ul>	<ol style="list-style-type: none"> <li>1. 2010 Interior 100% Acrylic Matte, Eggshell or Semi-Gloss</li> <li>2. Fres~Coat 100% Acrylic Latex Flat, Velvet Flat, Satin, Eggshell or Semi-Gloss</li> <li>3. Premium 100% Acrylic Latex Kitchen &amp; Bath, Eggshell or Semi-Gloss</li> <li>4. Larcoloid® 100% Acrylic Latex Gloss Enamel</li> <li>5. Pacific® Flat, Eggshell or Semi-Gloss</li> <li>6. Pro 2000 Flat, Eggshell or Semi-Gloss</li> <li>7. ProPaint® Flat, Eggshell or Semi-Gloss</li> <li>8. Fres~Coat Alkyd Eggshell or Semi-Gloss</li> <li>9. Preference Multi-Purpose Alkyd Gloss Enamel</li> <li>10. Larcoloid Urethane Alkyd Gloss</li> <li>11. Tuf-Quik® Urethane Enamel</li> <li>12. Tuf-Flex® Acrylic Epoxy</li> <li>13. Tile-Cote® Polyamide Epoxy</li> </ol>
ALKYD PRIMERS	FINISH COAT
<ul style="list-style-type: none"> <li>• Fres~Coat Alkyd Enamel Undercoat 20200 (easily sanded for fine finish work).</li> </ul>	<ol style="list-style-type: none"> <li>1. Fres~Coat Alkyd Eggshell or Semi-Gloss</li> <li>2. Larcoloid Urethane Alkyd Gloss</li> </ol>