



## SHEETROCK &amp; WALLBOARDS

## REPRESENTATIVE SURFACES

Walls  
Ceilings

## SURFACE PREPARATION

WARNING! If you scrape, sand or remove old paint from any surface, you may release lead dust. LEAD IS TOXIC. EXPOSURE TO LEAD DUST CAN CAUSE SERIOUS ILLNESS, SUCH AS BRAIN DAMAGE, ESPECIALLY IN CHILDREN. PREGNANT WOMEN SHOULD ALSO AVOID EXPOSURE. Wear a NIOSH-approved respirator to control lead exposure. Carefully clean up with a wet mop or HEPA vacuum. Before you start, find out how to protect yourself and your family by contacting the U.S. EPA/Lead Information Hotline at 1-800-424-LEAD (5323) or log on to [www.epa.gov/lead](http://www.epa.gov/lead).

## Interior

Sand all joints smooth taking care not to abraid the paper. Dust and dirt should be brushed off or vacuumed clean. Entire surface should then be primed with Fres~Coat® Acrylic Latex Enamel Undercoat 54600

## PRIMERS

Primers are normally not needed for latex finish coats. Fres~Coat® Acrylic Latex Enamel Undercoat 54600 will provide excellent hold-out for other coatings, and will not raise the grain as some other primers do.

**SHEETROCK & WALLBOARDS**

**PRODUCT RECOMMENDATIONS — SHEETROCK & WALLBOARDS**

EXPOSURE CONDITIONS	PRIMER	TOPCOAT
<b>Average Indoor Exposure</b> to mild industrial fumes and frequent washing	1) 100% ACRYLIC ENAMEL UNDERCOAT 2-4) NONE	1) TUF-QUIK® URETHANE 205XX SERIES 2) LATEX DRYFALL SPRAY FLAT 1030 3) RUST-STOP® DTM 100% ACRYLIC LATEX SEMI-GLOSS 4) LARCOLOID® 100% ACRYLIC LATEX GLOSS ENAMEL 511XX
<b>Severe Indoor Exposure</b> to water and splash of strong acids and alkalis	100% Acrylic Enamel Undercoat	TILE-COTE® EPOXY 1200 SERIES or TUF-FLEX® ACRYLIC EPOXY 1300
<b>Apply to Damp Surfaces</b>	NONE	SUPER DAMPCOAT® II 1901